



CAVALRY™

Assembly Guide

EN-CAU3I

Enclosure

Thank you for purchasing the CAU3I user-configured enclosure! The CAU3I enclosure is tough and cost-effective. It's designed to unleash the true speed of your hard-disk via the blindingly-fast next-generation USB 3.0 connection! The sturdy enclosure is easy to assemble and disassemble. The aluminum alloy transfers excess heat through the case--safely away from the delicate Hard Disk. Please read the entire guide before beginning the assembly.

The package contents include:

- ❖ CAU3I Enclosure Metal Lid & Drive-Tray
- ❖ USB 3.0 Cable, Stand and Screws
- ❖ CAU3I Quick-Start Guide
- ❖ CAU3I Power Supply

You will need (not included):

- ❖ One 3.5" SATA Hard Drive
- ❖ Philips-Head Screwdriver





- ❖ To reduce static discharge, do not assemble while on a carpeted surface. Please use anti-static wrist-straps and mats whenever possible.
- ❖ Handle hard drives on the sides only. Do not touch any exposed pins or connectors.

1 STEP ONE

Remove the box contents. Remove the four panel-screws and the plastic rear-panel.



2 STEP TWO

Remove the metal sleeve from the inner drive tray by sliding the sleeve backwards, away from the plastic front-panel. Take note of the rear end of the tray (containing the logic board) and the front end (containing the LED and plastic front-panel).

3 STEP THREE

Place your 3.5" SATAII drive into the tray at a 45 degree angle with the power and data ports carefully aligned to the power and data jacks on the logic board. Once aligned, slide carefully until you feel the plug firmly engage the drive-ports. **Be careful to avoid crimping the power wire!**





4 STEP FOUR

Place one hand securely over the top of the hard drive and slowly flip the drive and tray in order to expose the underside. Look for the four retainer screw-holes.



5 STEP FIVE

Place the drive and tray onto a clean stable work-surface, top-side down. Once securely in place, take a moment to check that the drive is still firmly mated with the logic-board.

6 STEP SIX

Insert the drive screws through the bottom of the tray until they engage the hard drive. Tighten them with your Philips head screw driver.



If you need any assistance assembling your drive, email us at CustomerSupport@CavalryStorage.com!



7 STEP SEVEN

Slide the metal sleeve over the tray, starting from the rear, until you feel the sleeve mate with the plastic front-panel.



8 STEP EIGHT

Place the plastic rear-panel over the rear of the tray. Take care to align the vent-holes on the panel with the vent-holes on the rear of the tray. Insert all four screws and tighten them with your screw-driver.

9 STEP NINE

Plug your drive in and power it on using the quick start guide instructions. Initialize and format your new blank* drive using these guides which are available at www.CavalryStorage.com/manuals.aspx :

- What is a Disk Management Utility?
- Disk Initialization and Formatting Guide



** Use the above guides when installing drives which have pre-existing data on them.*