

CAECUSB301

1. Package Contents

The following items are present in the package of the Cavalry USB 3.0 Express Card:

- USB 3.0 Express Card (CAECUSB301)
- This Quick Start Guide
- Product CD-ROM
- USB to DC Power Cable (item is dependent on bundle purchased)

Note: Package contents may vary.

2. Installation & Usage

- Turn on your notebook.
- Insert the USB 3.0 Express Card into a free ExpressCard/34 slot on your notebook.
Your notebook will show the “**New Hardware Wizard**” on your screen. You can ignore this “**New Hardware Wizard**” by clicking “**Cancel.**”
- Insert the CD-ROM in the optical drive of your computer. The Auto Play option will be shown automatically. Click on “**Run Autorun.exe**” to start the autorun menu.
- Select “**Install Drivers**” and follow the onscreen instructions to install the required drivers for the USB 3.0 Express Card.
- When the driver installation is complete, restart your notebook to ensure the drivers are correctly loaded.

Note: Some USB devices might require more power than can be provided by the USB 3.0 Express Card. For those devices, you can add extra power to the USB 3.0 Express Card with the optional USB to DC power cable.

Connect the USB connector of the USB to DC power cable to a free USB port on your notebook and the DC connector to the power connector on the side of the USB 3.0 Express Card. You can also use an external power supply (5V) instead of the USB to DC power cable.

Your Cavalry USB 3.0 Express Card is ready to use.
